

## Operation Instructions


Step1: Please download the software and install it.

ist > TPMS Update Assist

名称	修改日期
config.ini	2025/4/7 14:57
regioncode.txt	2024/10/19 16:44
TPMS Update Assist.exe	2025/3/6 11:50
unins000.exe	2025/3/6 11:19
update.exe	2025/3/6 11:50
api-ms-win-core-console-l1-1-0.dll	2019/7/30 8:52
api-ms-win-core-datetime-l1-1-0.dll	2019/6/24 19:53

Step2: Connect the device to the computer then open the App, and select the update option on the TPMS90 device.

Step3: Select the "Installed" option and uninstall all the files in the installed list.



Step4: Select the "Upgrade" option to upgrade

